


HƯỚNG DẪN CÀI ĐẶT MODEM TP-LINK ARCHER C2

1. Đăng nhập vào modem

Đăng nhập vào trang quản lý của modem: Địa chỉ mặc định là **192.168.0.1**, được in ở nhãn dưới đáy modem. Tên đăng nhập và mật khẩu đăng nhập mặc định cũng được in ở mặt dưới modem.

Mặc định ban đầu khi truy nhập vào modem, sẽ có thông báo cấu hình tên đăng nhập và mật khẩu mới.



2. Cài đặt Internet:

Truy nhập và mục **Network WAN** để cấu hình Internet cho modem

The image shows a screenshot of a modem's web interface for configuring WAN settings. The page title is "WAN QaHiqgg". On the left, there is a navigation menu with options like "Quick Setup", "Network", "-LAN", "-MAC Clone", "Dual Band Select", "Wireless 2.4GHz", "Wireless 5GHz", "Guest Network", "DHCP", "USB Settings", "NAT", "Forwarding", "Security", "Parent Control", "Access Control", "Advanced Routing", "Bandwidth Control", "IP & MAC Binding", "Dynamic DNS IPv6", "System Tools", and "Logout".

The main configuration area includes the following fields and options:

- Connection Type:** A dropdown menu set to "PPPoE". A red callout bubble points to this menu with the text "Chọn PPPoE".
- Detect:** A button next to the Connection Type dropdown.
- ppp Username:** A text input field containing "lhnsl-testload-". A red callout bubble points to this field with the text "Nhập Username hợp đồng khách hàng".
- PPP Password:** A password input field with masked characters. A red callout bubble points to this field with the text "Nhập Password hợp đồng khách hàng".
- Confirm password:** A second password input field with masked characters.
- Secondary Connection:** Radio buttons for "Disabled" (selected), "Dynamic IP", and "static IP (For Dual Access)".
- Connection Mode:** Radio buttons for "Always on" (selected), "Connect on demand", and "Connect manually".
- Max Idle Time:** A text field set to "115 minutes (0 meaning connection remains)".
- Authentication Type:** A dropdown menu set to "AUTO_AUTH".
- Connect / Disconnect:** Two buttons at the bottom of the configuration area.
- Save:** A large button at the very bottom of the page. A red callout bubble points to this button with the text "Click Save để lưu cấu hình".

At the bottom right of the page, there is a "Advanc" button, likely for "Advanced" settings.